

Boundary Pipe Elements

Step 3 - Boundary Pipe Elements screen allows you to designate alternate pipes that will act as boundary elements during the trace analysis. The pressure zone trace analysis will consider any pipes in the list below as a boundary element and it will halt the pressure zone trace analysis at the selected element. This feature can be useful if you wish to define a pressure zone by political or geographical boundaries rather than by pressure considerations alone.

To use this feature, select **Add Pipe** to select boundary pipes one at a time or use the **Select Elements** button to select multiple elements which define a zone. Upon completion of the map selection process, press the **Enter** key or right-mouse click and select **Enter** or **Cancel** from the menu to proceed. The selected pipes will be listed in the Pipe ID and Description fields. To delete a pipe ID from the list, highlight the ID from the list and select **Delete Row** to delete. To highlight the selected elements on the screen, use the **Show Elements** button.

Use **Next** to proceed to the next screen, or use the **Back** button to go to the previous screen.

Step 3 - Boundary Elements

Boundary Elements
All user defined boundary elements will be used to separate pressure zones.

Please specify all elements which separate pressure zones: Import Selection Set

ID	Type
101	Reservoir

Add Row Delete Row Show Element Select Elements

< Back Next > Cancel