

# InfoWater Pro Help Documentation

## Welcome to the InfoWater Pro Online Help

This online help contains documentation and is a central hub for InfoWater Pro.

Click on the icons below to view specific section contents, or use the navigation bar on the left to find the page that you need. You can also use the search bar to locate specific topics.



What's New



Getting Started



Installation



How to

## Table of contents

### [What's New](#)

### [Getting Started](#)

- [Installation and Licensing](#)
- [Upgrade and Update InfoWater Pro](#)
- [Quick Start Tutorial](#)
- [Technical Support](#)

### [Using InfoWater Pro](#)

- [User Interface](#)
  - [ArcGIS Pro Interface](#)
  - [InfoWater Pro Ribbon](#)
  - [InfoWater Pro Model Explorer](#)
    - [Attribute Toolbar](#)
  - [InfoWater Pro Message Board](#)
- [Setting Preferences and Default Values](#)
  - [Operation Settings](#)
  - [Display Settings](#)
  - [Default Symbols](#)
  - [Selection Settings](#)
  - [Labeling](#)
  - [Network Trace](#)
  - [ID and Description](#)
  - [ArcGIS Online Connect](#)
  - [Default Values](#)
- [Model Elements](#)

- Junction
- Reservoir
- Tank
- Pump
- Valve
- Pipe
- Digitize Network
- Edit Geometry
- Model Network
  - Fill Pipe Connectivity
  - Append Nodes
  - Utility - Network Review
  - Change ID
  - Merge Nodes
  - Switch Nodes
- Curves
- Patterns
- Controls
  - Initial Status
  - Initial Quality
  - Simple Control
  - Rule-Based Control
  - Variable Speed Pump Control
  - Remote Valve Control
- Domain Manager
- Facility Manager
- Database Management
  - Database Editor
  - Database Query
  - Database Query Set
  - Selection Set
  - Group Editing
  - Engineering Validation Manager
- Scenario Management
  - Scenario Explorer - General
  - Scenario Explorer - Facility
  - Scenario Explorer - Dataset
  - Dataset Manager
  - Scenario Comparison
- Running a Model
  - Run Manager
    - Simulation Options
    - Simulation Time
    - Simulation Report
    - Explicit VSP
  - Steady State Simulation
  - EPS Simulation
  - Water Quality
  - Energy
  - Sustainability Modeling
  - Fireflow
  - Multi-Fireflow
  - Pipe Break
  - Hydrant Curve
  - System Curve
  - SCADA Run
  - Batch Simulation Manager
- Analyzing Output Results
  - Report Manager
  - Tabular Report
  - Graph Report
  - Reference Graph
  - Graph Properties
  - Stored Graph
  - Thematic Mapping
  - Animation
  - Contour
  - Annotation
  - Fireflow Run Results
  - Output Unit Manager
  - Customized Report
  - Query Report
  - Query Summation Report
  - Output Relate
- Data Exchange
  - Import and Export EPANET
  - GIS Gateway
  - Import and Export Manager
  - ODBC Exchange

- Merge Model
- Real Time Data Connection
- How to Import an InfoWater model file into InfoWater Pro
- Live Data Adapter
- System Schematic
- 3D Display

## InfoWater Pro Apps

- Allocator
  - Demand Allocator Interface
  - Registering Layers
    - Importing Layers
    - Polygon Layer Registration
  - Allocating Demand
    - Allocation Methods
      - Polygon Extraction
      - Polygon Intersection
      - Geocoded Meter Billing Data
      - Closest Junction
      - Closest Pipe
      - Meter-Junction Allocation
      - Meter-Pipe Allocation
      - Import Meter Data
      - Meter Assignment
      - Edit Polygon Attribute
      - Create Thiessen Polygon
    - Demand Allocation Manager - Allocation Tab
    - Demand Allocation Manager - Usage Data
    - Usage Data
    - Allocation Parameters
    - Allocation Options
    - Allocator Report and Water Duty Calculator
- BTX Manager
  - InfoWater Pro BTX Overview
  - BTX Interface
    - Run Model - BTX
    - Trace Model - BTX
    - Display - BTX
  - Quick Start Tutorial - BTX Manager
- Calibrator
  - Calibration Concepts
  - Calibrator: User Interface
  - Calibration Modes
    - Steady State Calibration Mode
    - Fire Flow Test Calibration
    - Extended Period Calibration
  - Steady State - Calibrator
    - Roughness Group
    - Junction Pressure
    - Demand Group
    - Pipe Flow
    - Pipe Status
    - Run
    - Run Summary
    - Export Results
  - Fire Flow for Calibrator
    - Roughness Group: Fire Flow
    - Fire Flow Measurement
    - Run: Fire Flow
    - Run Summary: Fire Flow
    - Export Results: Fire Flow
  - Extended Period Simulation - Calibrator
    - Roughness of Extended Period Simulation
    - Junction Pressure of Extended Period Simulation
    - Pipe Flow of Extended Period Simulation
    - Tank Head/Level of Extended Period Simulation
    - Run of Extended Period Simulation
    - Run Summary of Extended Period
    - Export Results of Extended Period
  - Quick Start Tutorial - Calibrator
    - Steady State Model Calibration
- Criticality Assessment Manager
  - InfoWater Pro Criticality Assessment Manager Overview
  - Criticality Assessment Manager Interface
    - Criticality Assessment Manager - Based on Model Elements
    - Criticality Assessment Manager - Based on GIS Layer Elements
    - Criticality Assessment Manager - Save Results CSV
- Demand Analyst
  - DemandAnalyst Interface

- Demand Analyst Workflow
  - Edit Mapping
  - Usage Partition
- Demand Analyst Overview
- Demand Analyst Preface
- Demand Analyst tabs
  - Pattern Tab
  - Pattern Verification Tab
  - Meter Pattern Tab
  - Junction Pattern Tab
  - Summary
- Meter Connection Dialog Box
- Designer
  - Steady State
    - Designer - Input Data
    - Designer - Simulation
    - Designer - Output Report
    - Designer - Export
  - Fire Flow
    - Fire Flow - Input Data
  - Extended Period Simulation
    - Extended Period Simulation: Input Data
    - Extended Period Simulation - Simulation
    - Extended Period Simulation - Output Report
    - Extended Period Simulation - Export
  - Designer: Options
    - Advanced Genetic Algorithms Options
- IWLive Manager
- NetVIEW
  - NetVIEW for InfoWater Pro Overview
  - User Interface for NetVIEW
    - Export InfoWater Project to Google Earth
    - NetVIEW Results in Google Earth
- Protector
  - Overview of Protector
    - Protector Options
    - CityWatch Overview
    - Send CityWatch Notification
  - Contamination
  - Isolation
  - Breakdown
  - Fire
  - Event Trace
  - Vulnerability
  - Alert
  - Notification
  - Message Log
- Pump System Analyst
- Pressure Zone Manager
  - InfoWater Pro's Pressure Zone Manager Overview
  - Introduction to InfoWater Pro's Pressure Zone Manager (PZM)
  - Getting Started with Pressure Zone Manager (PZM)
  - PZM Manager
  - Pressure Zone Wizard
    - Boundary Pipe Elements
    - Customize Zone Information
    - Define Trace Area
    - Intra-zone Elements
    - Pressure Zone Identification and Analysis
  - Pressure Zone Results - Hydraulic Profile Diagram
    - Pressure Zone Results - Hydraulic Profile Schema
    - Pressure Zone Results - Zone Summary
    - Pressure Zone Results - Boundary Elements
    - PZM Summary - Zones Summary
  - Yourtown Example
- Scheduler
  - Scheduler Overview
  - Scheduler Interface
  - Input Data
    - Control Group
    - Source Cost
    - Constraints
    - Options
  - Simulation
  - Output Report
    - Scheduler - Output Report
    - Output Report - Control Schedule
    - Output Report - Detail Tab
    - Output Report - Constraint

- Output Report - Summary
- Export
- Optimization
  - Components of Genetic Algorithms
  - Genetic Algorithm (GA)
  - Overview of Genetic Algorithm
  - Particle Swarm Optimization (PSO)
- Quick Start Tutorial: Scheduler
- Skeletonizer
  - Overview
    - Hydraulic Equivalency
    - RST Applications
  - Skeletonizer Interface
    - Skeletonizer Options
- UDF Interface
  - Flush Sequence Manager
  - Flush Zone Manager
    - Flush Zones
  - Flush Zone Statistics
  - Notify Affected Customers
  - Uni-Direction Flushing
- WQ Calibrator
  - WQ Calibrator - Overview
    - Water Quality Calibrator
      - Water Quality Calibration Options
    - WQ Calibration Concepts
      - WQ Calibration Formulation
      - WQ Genetic Algorithms
      - WQ Objective Function
  - WQ User Interface
    - Pipe Wall Coefficient Group
    - Junction Concentration
    - WQ Calibrator - Run
    - WQ Run Summary
    - WQ Calibrator - Export Results
    - Calibration Options - Advanced Genetic Algorithm (GA) Options
  - Calibration Analysis
    - Comparison Graph
    - Correlation Scatter Plot
    - Calibration Statistics

## InfoWater Pro Suite

- Multi Species Model
  - Base Model
  - General Tab
  - Species Tab
  - Term Tab
  - Parameter Tab
  - Constant Tab
  - Parameters, Initial Quality, and Water Quality Source
    - Multi-Species Node Quality
    - Multi-Species Link Quality
    - Multi-Species Link Parameter
    - Multi-Species Tank Parameter
- Hydraulic Calculator
- Pipeline Costing
- Info360 Connect
- InfoSurge
  - Identify Surge Elements
    - Junction Demand Change Data
    - Pump Operation Change
    - Active Valve (AV) Operation Change
    - Pipe Wave Speed
    - Surge Protection Device (SPD)
      - Side Discharge Orifice
      - Open Surge Tank
      - One Way Surge Tank
      - Closed Surge Tank
      - Bladder Surge Tank
      - Rupture Disk
      - Pressure Relief Valve
      - Surge Anticipation Valve
      - 1 and 2 Stage Air Vacuum Valve
      - 3 Stage Air Vacuum Valve
      - Hydraulically Actuated Anticipation Valve
      - Electrically Actuated Anticipation Valve
  - Auxiliary Calculator
- Elevation Extractor

## Recent updates



Marybeth Bailey

[Quick Start Tutorial: Scheduler](#) updated about 2 hours ago • [view change](#)

[Quick Start Tutorial - BTX Manager](#) updated Apr 03, 2020 • [view change](#)

[Quick Start Tutorial - Calibrator](#) updated Apr 03, 2020 • [view change](#)

[Steady State Model Calibration](#) updated Apr 02, 2020 • [view change](#)

[What's New](#) updated Apr 02, 2020 • [view change](#)