


Flush Zone Statistics

The Flush Zone Statistics command provides report information about the current flush zone to include the number of sequences, the total length of pipe flushed, the flush volume, the time required, the number of hydrants, and the number of valve operations involved.

A dialog box titled "Flush Zone Statistics" with a close button (X) in the top right corner. It contains a table with two columns: "Report Item" and "Value". The table lists eight items related to flush zone statistics. A "Close" button is located at the bottom right of the dialog box.

	Report Item	Value
1	Flush Zone	ZONE1
2	Number of Flush Sequences	27
3	Total Flush Length	23,753.5 ft
4	Total Flush Volume	1,335,601.6 gal
5	Total Flush Time	1,364.7 min.
6	Number of Hydrant Operations	27
7	Number of Valve Closing	30
8	Number of Valve Opening	27