

Table of Contents

Table of Contents

What's New

- What's New
- Features in Previous Releases
- Release Notes

Installation Guide

- System Requirements
- Installation and Licensing
- Third Party Downloads

Getting Started

- Upgrade and Update InfoWater Pro
- Quick Start Tutorial
- InfoWater Pro's Online Help
- How to Import an InfoWater model file into InfoWater Pro
- How to Upload an InfoWater Pro model into Info360 Insight
- Index of InfoWater Pro's online help documentation

Using InfoWater Pro

- User Interface
 - ArcGIS Pro Interface
 - InfoWater Pro Ribbon
 - InfoWater Pro Model Explorer
 - Attribute Toolbar
 - InfoWater Pro Message Board
- Setting Preferences and Default Values
 - Operation Settings
 - Display Settings
 - Default Symbols
 - Selection Settings
 - Labeling
 - Network Trace
 - ID and Description
 - ArcGIS Online Connect
 - Default Values
- Model Elements
 - Junction
 - Reservoir
 - Tank
 - Pump
 - Valve
 - Pipe
 - Digitize Network
 - Edit Geometry
- Model Network
 - Fill Pipe Connectivity
 - Append Nodes
 - Utility - Network Review
 - Change ID
 - Merge Nodes
 - Switch Nodes
- Curves
- Patterns
- Controls
 - Initial Status
 - Initial Quality
 - Simple Control
 - Rule-Based Control
 - Variable Speed Pump Control
 - Remote Valve Control
- Domain Manager
- Facility Manager
- Database Management
 - Database Editor
 - Database Query
 - Database Query Set
 - Selection Set
 - Group Editing
 - Engineering Validation Manager
- Scenario Management
 - Scenario Explorer - General
 - Scenario Explorer - Facility

- Scenario Explorer - Dataset
- Dataset Manager
- Scenario Comparison
- Running a Model
 - Run Manager
 - Simulation Options
 - Simulation Time
 - Simulation Report
 - Explicit VSP
 - Steady State Simulation
 - EPS Simulation
 - Water Quality
 - Energy
 - Sustainability Modeling
 - Fireflow
 - Fireflow Extended Tutorial
 - Multi-Fireflow
 - Pipe Break
 - Hydrant Curve
 - System Curve
 - SCADA Run
 - Batch Simulation Manager
- Analyzing Output Results
 - Report Manager
 - Tabular Report
 - Graph Report
 - Reference Graph
 - Graph Properties
 - Stored Graph
 - Thematic Mapping
 - Animation
 - Contour
 - Annotation
 - Fireflow Run Results
 - Output Unit Manager
 - Customized Report
 - Query Report
 - Query Summation Report
 - Output Relate
- Data Exchange
 - Import and Export EPANET
 - GIS Gateway
 - Import and Export Manager
 - ODBC Exchange
 - Merge Model
 - Real Time Data Connection
- Tools
 - 3D Display
 - Elevation Extractor
 - Hydraulic Calculator
 - Info360 Connect
 - Live Data Adapter
 - LDA - Bulk Import
 - Pipeline Costing
 - Project Synchronization
 - System Schematic

InfoWater Pro Apps

- Allocator
 - Demand Allocator Interface
 - Registering Layers
 - Importing Layers
 - Polygon Layer Registration
 - Allocating Demand
 - Allocation Methods
 - Polygon Extraction
 - Polygon Intersection
 - Geocoded Meter Billing Data
 - Closest Junction
 - Closest Pipe
 - Meter-Junction Allocation
 - Meter Summation
 - Import Meter Data
 - Meter Assignment
 - Edit Polygon Attribute
 - Create Theissen Polygon
 - Demand Allocation Manager - Allocation Tab
 - Demand Allocation Manager - Usage Data
 - Usage Data

- Allocation Parameters
 - Allocation Options
 - Allocator Report and Water Duty Calculator
- Quick Start Tutorial: Allocator
- BTX Manager
 - InfoWater Pro BTX Overview
 - BTX Interface
 - Run Model - BTX
 - Trace Model - BTX
 - Display - BTX
 - Quick Start Tutorial - BTX Manager
- Calibrator
 - Calibration Concepts
 - Calibrator: User Interface
 - Calibration Modes
 - Steady State Calibration Mode
 - Fire Flow Test Calibration
 - Extended Period Calibration
 - Steady State - Calibrator
 - Roughness Group
 - Junction Pressure
 - Demand Group
 - Pipe Flow
 - Pipe Status
 - Run
 - Run Summary
 - Export Results
 - Fire Flow for Calibrator
 - Roughness Group: Fire Flow
 - Fire Flow Measurement
 - Run: Fire Flow
 - Run Summary: Fire Flow
 - Export Results: Fire Flow
 - Extended Period Simulation - Calibrator
 - Roughness of Extended Period Simulation
 - Junction Pressure of Extended Period Simulation
 - Pipe Flow of Extended Period Simulation
 - Tank Head/Level of Extended Period Simulation
 - Run of Extended Period Simulation
 - Run Summary of Extended Period
 - Export Results of Extended Period
 - Quick Start Tutorial - Calibrator
- Criticality Assessment Manager
 - Introduction to InfoWater Pro Criticality Assessment Manager
 - InfoWater Pro Criticality Assessment Manager Overview
 - Criticality Assessment Manager Interface
 - Criticality Assessment Manager - Based on Model Elements
 - Criticality Assessment Manager - Based on GIS Layer Elements
 - Criticality Assessment Manager - Save Results CSV
 - Notify Affected Customers - CAM
 - Criticality Assessment Manager: Reports
 - Criticality Assessment Manager: Standard Reports
 - CAM Reports - Affected Category Demand
 - CAM Reports - Affected Total Demand
 - CAM Reports - Pound Facilities
 - CAM Reports - Pound Junctions
 - CAM Reports - Pound Pipes
 - CAM Reports - Closed Elements
 - CAM Reports - Isolated Junctions
 - CAM Reports - Low Pressure Junctions
 - CAM Reports - No Water Junctions
 - CAM Reports - Pressure Violation Junctions
 - CAM Reports - Velocity Violation Pipes
 - CAM Reports - Flow Reversal Pipes
 - Save Results to CSV File
 - Criticality Assessment Manager: Extended Reports
 - CAM Reports - Extended Valve Assessment Reports
 - Extended Reports - Affected Area Reports
 - Extended Reports - Detailed Element Reports
 - Extended Reports - Performance Reports
 - Quick Start Tutorial: CAM
- Designer
 - Steady State
 - Designer - Input Data
 - Designer - Simulation
 - Designer - Output Report
 - Designer - Export
 - Fire Flow
 - Fireflow - Input Data

- Fireflow - Simulation
 - Fireflow - Output Report
 - Fireflow - Export
- Extended Period Simulation
 - Extended Period Simulation: Input Data
 - Extended Period Simulation - Simulation
 - Extended Period Simulation - Output Report
 - Extended Period Simulation - Export
- Designer: Options
 - Advanced Genetic Algorithms Options
- Quick Start Tutorial: Designer
- IWLIVE Manager
- NetVIEW
 - NetVIEW for InfoWater Pro Overview
 - User Interface for NetVIEW
 - Export InfoWater Project to Google Earth
 - NetVIEW Results in Google Earth
- Protector
 - Overview of Protector
 - Protector Options
 - CityWatch Overview
 - Send CityWatch Notification
 - Contamination
 - Isolation
 - Breakdown
 - Fire
 - Event Trace
 - Vulnerability
 - Alert
 - Notification
 - Message Log
 - Quick Start Tutorial: Protector
- Pump System Analyst
- Pressure Zone Manager
 - InfoWater Pro's Pressure Zone Manager Overview
 - Introduction to InfoWater Pro's Pressure Zone Manager (PZM)
 - Getting Started with Pressure Zone Manager (PZM)
 - PZM Manager
 - Pressure Zone Wizard
 - Define Trace Area
 - Intra-zone Elements
 - Boundary Pipe Elements
 - Customize Zone Information
 - Pressure Zone Identification and Analysis
 - Pressure Zone Results - Hydraulic Profile Diagram
 - Pressure Zone Results - Hydraulic Profile Schema
 - Pressure Zone Results - Zone Summary
 - Pressure Zone Results - Boundary Elements
 - PZM Summary - Zones Summary
 - Quick Start Tutorial: Yourtown Example
- Scheduler
 - Scheduler Overview
 - Scheduler Interface
 - Input Data
 - Control Group
 - Source Cost
 - Constraints
 - Options
 - Simulation
 - Output Report
 - Scheduler - Output Report
 - Output Report - Control Schedule
 - Output Report - Detail Tab
 - Output Report - Constraint
 - Output Report - Summary
 - Export
 - Optimization
 - Components of Genetic Algorithms
 - Genetic Algorithm (GA)
 - Overview of Genetic Algorithm
 - Particle Swarm Optimization (PSO)
 - Quick Start Tutorial: Scheduler
- Skeletonizer
 - Overview
 - Hydraulic Equivalency
 - RST Applications
 - Skeletonizer Interface
 - Skeletonizer Options
 - Quick Start Tutorial: Skeletonizer

- WQ Calibrator
 - WQ Calibrator - Overview
 - Water Quality Calibrator
 - Water Quality Calibration Options
 - WQ Calibration Concepts
 - WQ Calibration Formulation
 - WQ Genetic Algorithms
 - WQ Objective Function
 - WQ User Interface
 - Pipe Wall Coefficient Group
 - Junction Concentration
 - WQ Calibrator - Run
 - WQ Run Summary
 - WQ Calibrator - Export Results
 - Calibration Options - Advanced Genetic Algorithm (GA) Options
 - Calibration Analysis
 - Comparison Graph
 - Correlation Scatter Plot
 - Calibration Statistics
 - Quick Start Tutorial: WQ Calibrator

InfoWater Pro Suite

- Multi-Species Model
 - Base Model
 - General Tab
 - Species Tab
 - Term Tab
 - Parameter Tab
 - Constant Tab
 - Parameters, Initial Quality, and Water Quality Source
 - Multi-Species Node Quality
 - Multi-Species Link Quality
 - Multi-Species Link Parameter
 - Multi-Species Tank Parameter
- InfoWater Pro UDF
 - UDF Overview
 - UDF Configuration
 - Set UDF Layer
 - Auto Associate Hydrant
 - Auto Associate Valve
 - Import UDF Data
 - Edit UDF Data
 - Assign Emitter Coefficient
 - Interpolate Hydrant Elevation
 - Calculate Length of Hydrant Lateral
 - Color Code Flush Zones
 - Draw Hydrant-Pipe Association Linkage
 - UDF Data QA/QC
 - UDF Options
 - UDF Interface
 - Flush Zone Statistics
 - Notify Affected Customers
 - The UDF Attribute Browser
 - Flush Zone Manager
 - Flush Zones
 - UDF - Flush Zone Manager
 - Flush Sequence Manager
 - Flush Sequences
 - Flush Sequence Manager - General Tab
 - Flush Sequence Manager - Operations Tab
 - Flush Sequence Manager - Parameters Tab
 - Flush Sequence Manager - Pipe Results Tab
 - Flush Sequence Manager - Critical Junctions Tab
 - Flush Sequence Manager - Notes
 - UDF Field Journal
- Demand Analyst
 - DemandAnalyst Interface
 - Demand Analyst Workflow
 - Usage Partition
 - Edit Mapping
 - Demand Analyst Overview
 - Demand Analyst Preface
 - Demand Analyst tabs
 - Pattern Tab
 - Pattern Verification Tab
 - Meter Pattern Tab
 - Junction Pattern Tab
 - Export Pattern
 - Create Thiessen Polygon Layer

- Meter Connection Dialog Box

InfoSurge Pro

- Installation and Configuration
- InfoSurge Capabilities
- Methodology of InfoSurge
 - Fundamentals of Hydraulic Transient
 - Numerical Solution Methods
 - Hydraulic Characteristic of Valves
 - Hydraulic Characteristics of Pumps
 - Pressure Surge Control Devices
 - Choice of Surge Protection Strategy
 - Cavitation
 - Pressure Sensitive Demand
 - Intrusion
- InfoSurge User Interface
 - InfoSurge Pipe Wave Speed
 - InfoSurge Pump Surge Data
 - InfoSurge Active Valve Data
 - InfoSurge Junction Demand Change Data
 - InfoSurge Pump Operation Change
 - InfoSurge Active Valve (AV) Operation Change
 - InfoSurge Protection Device
 - Surge Calculators
 - Identify Surge Elements
 - Junction Demand Change Data
 - Pump Operation Change
 - Active Valve (AV) Operation Change
 - Pipe Wave Speed
 - Surge Protection Device (SPD)
- Creating Transients
 - Pump Operation
 - Pump Speed Change
 - Pump Startup
 - Pump Trip
 - Valve Operation
 - Junction Demand Change
- Running a Surge Analysis
- Viewing Surge Results
- General Surge Modeling Tips
- Frequently Asked Questions
- Troubleshooting
- InfoSurge Quick Start Tutorial