

Inflows


Inflows are sources of flows for the Site. Click on the individual Inflow links to the right to see specific input details.



[Back to: Help Documentation](#)

Common Tabs

Runoff/Hydrograph



Details of the specific Inflow are entered.

Pollution

Name

The name of the pollutant, as listed on the [Pollutants](#) form

Concentration

Enter the concentration of the pollutant as it washes off the Area or Hydrograph. This is a constant rate of concentration.

Land Use

Applies only to Catchment Area, Green Roof and Roof. Currently used to specify Percentage Impervious for the Advanced [Water Quality Calculator](#) Method (NYS Design Manual). Will be expanded at a later date.

Rainwater Tank

The option to include a rainwater tank which takes flow at the source. Follow the link above for specification details.

Section Pages

- [Catchment Area](#)
- [Green Roof](#)
- [Hydrograph](#)
- [Roof](#)
- [Rainwater Tank](#)

Workflow - What's next...?



Connect Inflows to your **Stormwater Control**, specify **Inlets** or **Outlets** or connect to another Stormwater Control or **Junction**.