

Allocating Demand

Once the primary and secondary layers have either been created or registered, you can now begin the allocation process to assign demand to the network nodes.

- [Allocation Methods](#)
- [Demand Allocation Manager - Allocation Tab](#)
- [Demand Allocation Manager - Usage Data](#)
- [Usage Data](#)
- [Allocation Parameters](#)
- [Allocation Options](#)
- [Allocator Report and Water Duty Calculator](#)