


Steady State

You can access Steady State in the Designer application of InfoWater Pro by clicking on **InfoWater Pro > Apps > App Manager** and select **Designer**. Click on the **Run** button.



The screenshot shows the 'App Manager' window with a grid of application icons. The 'Designer' icon is highlighted with a red border, and a red arrow points to the 'BTX' icon. Below the grid, the 'System Designing App' section shows 'Available App Commands' with 'Designer' selected. At the bottom, there are 'Run' and 'Close' buttons.

App Name	Icon Description
Allocator	Blue square with white arrows pointing outwards
BTX	Green square with white BTX symbol and a red arrow pointing to it
Calibrator	Orange square with white factory icon
Criticality Assessment Manager	Orange square with white radiation symbol
DemandAnalyst	Dark grey square with white magnifying glass over a bar chart
Designer	Orange square with white pencil and paper icon (highlighted with a red box)
IWLIVE	Blue square with white Wi-Fi symbol
NetMEW	Green square with white globe and arrow icon
Protector	Dark grey square with white shield icon
PSA	Green square with white graph icon
PZM	Red square with white clock icon
Scheduler	Yellow square with white clock icon
Skeletonizer	Dark grey square with white grid icon
UDF	Red square with white gear and arrow icon
WQ Calibrator	Red square with white factory icon

System Designing App

Command	Description
<input checked="" type="checkbox"/> Designer	Launch Designer

Ready, Build 0.02

Run Close