


# Preferences

The **Preferences** form allows you to modify a variety of global settings.



## General

**Allowable Undos** - Sets the maximum number of Undo/Redo actions that are maintained. The higher the value the bigger the amount of disk space and processing time is used.

**Analysis Mode** - The analysis mode dicates how the results of are maintained.

**User** - The analysis must be performed manually by using the Go option.

**Background** - The analysis will be run automatically in the background when changes are made to ensure results are always available. Results forms are closed.

**Maintain Results** - The analysis will be run automatically in the background when changes are made to ensure the results are always available. Results forms are updated.

**Messages and Prompts** - Allows the messages and prompts to be returned to the default settings. This includes the 'Do Not Show This' again messages which may have been turned off inadvertently.

**Autosave** - Allows to autosave every T (mins) interval (See [Autosave - Recovery](#)).

**Show Welcome Screen** - Set this checkbox to enable or disable viewing the [Welcome to InfoDrainage](#) on program start.

## Regionalisation

**Region** - Attempts to set the Region for the current file. Note that if there are items in the current design that are not available under the specified region, the user will be warned as such and the region will default to Global

**Units** - Allows the user to customise the units used throughout the software to suit their needs.

For more information about this topic, go to [Regionalisation](#).