

Project Templates

Project Templates can be created to provide a starting point the user wishes to use for one or more designs. When a Project Template is created from a file, most design specific information is removed, and the following is left behind:

- **Object Templates** - The current template file path, if available
- **Hard Copy Headings** - The current Hard Copy Headings information
- **Preferences** – The current units
- **Display Settings** - The current display settings
- **Print Settings** - The last used printing settings
- **GIS Import / GIS Export** - Last used mapping for Connections, Junctions and Stormwater Controls, if available
- **CSV Import / CSV Export** - Last used mapping for Connections, Junctions and Stormwater Controls, if available
- **Rainfall Manager** - The current rainfall library path, if available
- **Pollutants** - The current set of pollutants
- **Preliminary Sizing** - The current Network Sizing Criteria, if available
- **Profile** - Colour and plot options
- **Analysis Criteria** - Currently selected analysis criteria
- **Comparison Report** - Phase comparison report options, if available

By default, a project template file is used based on your region, and is located in the InfoDrainage install directory.