

Display Settings

The **Display Settings** form allows you to set the various view display and property settings. The tabs on the **Display Settings** form give you access to specific areas of the views available.

Toolbar

The toolbar gives you the following options:

Open File - Locate and open an *.iddsx file that contains pre-set values for the Display Settings tabs.

Save File - Save the current Display Settings tab values to an *.iddsx file.

Default colours - Set the display colours for all items listed on the form to a predefined list of colours.

Default Deluge colours - Set the Deluge display colours to a predefined colour set.

Layers Tab


This table dictates the visibility, display colour and object control of the listed layer items.

The layers can be filtered using the drop-down list above the table. This allows the table to be reduced to only showing the layers required.

	Show	Colour	Select	Move	Delete
Inflow					
Inflow Outline					
Inflow Label					
Stormwater Control					
Stormwater Control Outline					
Stormwater Control Geometry					
Stormwater Control Label					
Junction					
Junction Label					
Connection					
Capacity Exceeded					
Connection Label					
Grid					
Background					
Selected Item					

Surface Tab


The table dictates the visibility and colour of the listed layer items. The [Colour Ramp](#) dictates the colours of the Contours and Colour Fill that can be rendered for a given set of [Surface Data](#).

 Items in this tab are only editable after a surface has been added to the current phase.


Display Settings
✕

Layers
Surface
Deluge
Plan
Profile
Flow Path

Surface

Ramp 

Blend RGB HSL



Restrict to Maximum

Edit Maximum (m)

Add (m)

Add

Edit (m)

Remove

Edit Minimum (m)

Restrict to Minimum

Opaque Transparent

	Show	Colour
Triangles	<input checked="" type="checkbox"/>	
Data	<input checked="" type="checkbox"/>	
Contours	<input checked="" type="checkbox"/>	
Surface Colour Fill	<input checked="" type="checkbox"/>	

Deluge Tab


The table dictates the visibility of the listed layer items.

Depth option

The [Colour Ramp](#) dictates the colours of the **Depth** that can be rendered after Deluge analysis for a given set of [Surface Data](#).

The Deluge water surface can be drawn as a series of independent grid levels (as analysed) or as a continuous surface. When **Show Continuous Surface** is selected, the grid level is applied at the centre of each grid square and the level linearly interpolated in between.

The **Level of Detail** slider allows you to specify the maximum number of grid squares that will be displayed along both axis of the Depth rendering.

 Items in the Deluge tab are only editable after a Deluge has been run.

The screenshot shows the 'Display Settings' window with the 'Deluge' tab selected. The interface includes a color ramp for 'Depth x Velocity' and several control panels:

- Color Ramp:** A vertical color bar transitioning from red at the bottom to purple at the top.
- Blend:** Radio buttons for 'RGB' (selected) and 'HSL'.
- Restrict to Maximum:** An unchecked checkbox.
- Edit Maximum (m):** A text input field containing '1.00' with a pink arrow icon to its left.
- Add (m):** A text input field containing '0.00' with a blue arrow icon to its left and an 'Add' button below it.
- Edit (m):** A text input field containing '0.83' with a green arrow icon to its left and a 'Remove' button below it.
- Edit Minimum (m):** A text input field containing '0.00' with a red arrow icon to its left.
- Restrict to Minimum:** An unchecked checkbox.
- Opacity:** A horizontal slider between 'Opaque' and 'Transparent'.
- Show:** A table with 'Depth' and 'Contours' rows, each with a lightbulb icon.
- Show Continuous surface:** A checked checkbox.
- Level of Detail Plan:** A vertical slider with 'High' at the top and 'Low' at the bottom.


At the bottom left, there are two tabs: 'Depth' (highlighted in orange) and 'Depth x Velocity'.

Depth x Velocity options

The [Colour Ramp](#) dictates the colours of the **Depth x Velocity** that can be rendered after Deluge analysis for a given set of [Surface Data](#).



Items in this tab are only editable after a Deluge has been run.



Plan Tab

The following fields are available in the **Plan** tab:

Text Height - Sets the text height on Plan.

Icon Height - Sets the maximum icon size when zooming on Plan.

Connection Line Width - Sets the line width used to render Connections (in pixels).

Grid Size - Sets the tick interval of the grid when shown on Plan.


Restore Plan view on Open - Sets the Plan to remember the view/zoom setting that was last used when re-opening.

Junction Transparency

Access Only or All Junctions - Decides what junctions are affected by the transparency slider.

- **Access Only** - Only affects junctions that require access.
- **All Junctions** - Affects all junctions on the plan.

Transparency Slider - Sets how transparent the objects appear on the Plan. The left-most side giving no transparency and the right-most side making them completely transparent.



Profile Tab

The table dictates the colours of the items shown on profile view, both in the primary window and on the **Plot Profile** form.

The layers can be filtered using the drop-down list above the table. This allows the table to be reduced to only showing the layers required. Layers can be turned on and off by clicking the lightbulb icon in their row.

You can also modify the following fields:

Font Size - Sets the annotation and axis text font size on the Profile.

Summary Font Size - Sets the font size for the Summary table on the Profile.

Display Settings

Layers Surface Deluge Plan Profile Flow Path


Profile

Filter By: All Font Size (pt) 8.0
Summary Font Size (pt) 8.0

	Show	Colour
Background		
Hor. Main Grid Lines	💡	
Hor. Sub Grid Lines	💡	
Ver. Grid Lines	💡	
Annotation	💡	
Freeboard		
Initial Depth		
Ponding Area		
Subsurface Area		
Manhole		
Under Drain		
Water Level		
Max Water		
Water Trace		
Surface	💡	
Ground	💡	
Notional Connections		
Pipe		
Box Culvert		
Rectangular Channel		
Trapezoidal Channel		
Triangular Channel		


Flow Path Tab

The table dictates the display colours of the listed [Flow Path](#) items.



Colour Ramp

The colour ramp shows the blended ramp used for Surface Elevation/Deluge rendering. If no pegs are defined, the blend is between the end peg colours. End peg values and colours can be adjusted as described below but they cannot be deleted. Moving the mouse over the ramp will display the elevation value at the mouse position. Pegs can be used to introduce a colour change in the blend. See Add and Remove below for peg editing. Right-click the Ramp to display a menu also described below.



Ramp

The drop-down menu provides several default colour ramps. Any of the colour ramps can be used with either Surface or Deluge. However, some are more appropriate than the others.

Blend

When blending the ramp between pegs, the control can blend the **RGB** (Red, Green, Blue) settings for the peg colours or the **HSL** (Hue, Saturation, Luminance) settings. Although the blending results can be very similar, the difference is more pronounced when blending 'opposite' colours e.g.: Green and Magenta.

Restrict to Maximum

If this checkbox is ticked, any value above the maximum value is not coloured on Plan.

If the checkbox is un-ticked, the maximum colour is used for all values equal to or above the maximum.

Edit Maximum

This field is the maximum value of the colour ramp. When used for the Surface, this value is set to the Maximum Z value from the surface.

Changing the value and/or the colour will update the Max peg. This field can be set to a value larger if required, but helper test at the bottom of the form shows the absolute maximum value.

Add

Clicking the colour ramp will enter a value, appropriate to its position, in this field. The colour is set to the colour at the click position. Alternatively, you can enter a value and a colour. Clicking **Add** will add a new peg.

Edit

Clicking a peg will enter the peg details in this field. Changing the value and/or the colour will update the selected peg.

Remove

When a peg is selected, clicking **Remove** will delete the peg.

Edit Minimum

This field is the minimum value of the colour ramp. When used for the Surface, this value is set to the Minimum Z value from the surface.

Changing the value and/or the colour will update the Min peg. This field can be set to a smaller value if required, but helper test at the bottom of the form shows the absolute minimum value.

Restrict to Minimum

If this checkbox is ticked, any value below the minimum value is not coloured on Plan.


If the checkbox is un-ticked, the minimum colour is used for all values equal to or below the minimum.

Opaque – Transparent

Moving the slider sets the transparency of the colours on Plan. The transparency setting is not reflected on the ramp.

Right-Click menu

The Right-click menu on the Ramp provides some simple adjustment actions.



Even Space Pegs - Evenly distributes the pegs on the ramp.

Narrow Space Pegs - Distributes the pegs with a bias towards the minimum.

Invert Space Pegs - Reverses the peg distribution.

Invert Colour Ramp - Reverses the ramp colours settings.

Double Pegs - Doubles the number of pegs. Typically when viewing contours, this option will double the number of contours.

Delete Pegs - Deletes all the intermediate pegs but not the end peg Min and Max settings