

Time of Concentration

The amount of time that it will take for water landing on the roof area to enter the system. The inflows from the area will then be evenly spread over this time when the area is analysed.

This amount of time can be calculated with the [Time Of Concentration Calculator](#).

Analysis

The analysis is the same as the [Time Area Diagram](#) method with the time area diagram being built with an even spread of the area over the time of concentration.

Eg. Time of Concentration = 3 mins, Area = 0.75ha

If the timestep is 1 minute, A1 = 0.25, A2 = 0.25, A3 = 0.25.

The rainfall profile and the time area diagram are combined with the volumetric runoff coefficient in the following way:

$$Q_1 = (I_1 \times A_1) \times 2.78 \times C_v$$

$$Q_2 = (I_1 \times A_2 + I_2 \times A_1) \times 2.78 \times C_v$$

$$Q_3 = (I_1 \times A_3 + I_2 \times A_2 + I_3 \times A_1) \times 2.78 \times C_v$$

And so on...



[Back to: Help Documentation](#)

Section Pages

- [Green Roof Runoff Method](#)
- [Time of Concentration](#)
 - [Time Of Concentration Calculator](#)
- [SCS](#)
 - [Curve Number Calculator](#)
- [Santa Barbara Urban Hydrograph](#)
- [Time Area Diagram](#)
- [UK Unit Hydrographs](#)
- [FSR Unit Hydrograph](#)
- [FEH Unit Hydrograph](#)
- [ReFH Unit Hydrograph](#)
- [Laurenson](#)

Workflow - What's next...?



Inflows connect to either **Junctions** or **Stormwater controls** via **Inlets**.

Specify an **Outlet** on these objects then choose to connect to another Junction or Stormwater Control.